

You have downloaded a manual for our

**SCOTCHMAN
MODEL
CPO-315-HFA-5HP
COLD SAW**

**Please download our .pdf
"Cold Saw Blade Basics" too.**

**Please read both of the above
before operating this saw!!**

WWW.SCOTCHMAN.COM



www.scotchman.com

MODEL
CPO-315-HFA-5HP
COLD SAW

S/N B1491 HFA 0622 & UP

PRINTED APRIL 2023

TABLE OF CONTENTS

SECTION	DESCRIPTION	PAGE #
1.0	INTRODUCTION	4
2.0	SAFETY PRECAUTIONS	4
3.0	WARRANTY	5
4.0	INSTALLATION & SET-UP	6
4.1	Physical Dimensions	6
4.2	Machine Installation	8
4.3	Electrical Requirements	10
4.4	Coolant System	11
5.0	MACHINE START-UP	11
5.1	Control Panel Functions	12
5.1A	Main Power Switch	13
5.1B	Motor Control Switch	13
5.1C	Power Up Switch	13
5.1D	Emergency Stop Switch	13
5.1E	Head Up	14
5.1F	Head Down	14
5.1G	Hitch Selector	14
5.1H	Cycle/Start Button	14
5.1I	Automatic/Manual Switch	14
5.1J	Trim/Test	15
5.1K	Coolant Pump Switch	15
5.1L	Variable Motor Speed Control	15
5.1M	Counter	15
5.1N	Feed Rate Control	16
5.1O	Power Indicator Light	16
6.0	MACHINE OPERATION	16
6.1	Selecting The Proper Blade and Cutting Speed	16
6.2	Blade Installation	18
6.3	Saw Capacities	21
6.4	Material Main Vise	22
6.5	Shuttle Vise & Cylinder	25
6.6	Power Down Feed	26
6.7	Material Clamping	28
6.8	Stroke Control Adjustment	28
6.9	Counter Set-up	30
7.0	MACHINE AUTOMATIC OPERATION (SET-UP)	32
8.0	MAINTENANCE	34
8.1	Lubrication	34

TABLE OF CONTENTS

SECTION	DESCRIPTION	PAGE #
	8.2 Cutting Oils and Lubricants	35
	8.3 Scheduled Maintenance	35
	8.4 Gear Replacement (Saw Head)	36
	8.5 Spindle Replacement (Main Vise)	38
	8.6 Seal Replacement (Main Vise)	39
	8.7 Shuttle Vise Maintenance	40
	8.8 Coolant Pump Maintenance	42
9.0	OPTIONAL EQUIPMENT	44
	9.1 Special Vise Jaws	44
	9.2 Optional In Feed Supply Tracks	44
10.0	TROUBLE SHOOTING GUIDE	46
	10.1 Electrical Trouble Shooting	46
	10.2 Breakage or Excessive Dulling of Blades	46
	10.3 Part Length Is Not Consistent	47
	10.4 Flood Coolant System (Optional)	47
	10.5 PLC Troubleshooting	48
	10.6 Pneumatic System	50
11.0	PARTS LISTS	52
	11.1 Saw Head	52
	11.2 Main Vise Assembly	54
	11.3 Shuttle Vise Assembly	56
	11.4 Shuttle Assembly	58
	11.5 Fine Adjustment Stop Assembly	60
	11.6 Power Down Feed Assembly	62
	11.6A Power Down Feed Valves	64
	11.6B Air Controls	66
	11.7 Air Valve Assembly	68
	11.8 Blade Guard Assembly	70
	11.9 Motor Assembly	72
	11.10 Electrical Unit-Line Circuit	74
	11.11 Electrical Unit-Secondary Circuit	76
	11.12 Base Assembly	78
	11.13 Coolant Pump	80
	11.14 Stroke Control Assembly	82
	11.15 Hood Assembly	84
12.0	OPTIONAL EQUIPMENT PARTS LISTS	86
	12.1 Supply Track Assembly	86
	12.2 Cutting Coolants and Lubricants	88
	12.3 Vise Pressure Regulator	88
	12.4 Shuttle Vise Pressure Regulator	90
13.0	SAFETY VALVE / SOLENOID	92
14.0	WIRING DIAGRAMS	93
15.0	STOCK BLADES	97

1.0 INTRODUCTION

The CPO-315 HFA Fully Automatic Cold Saw is designed to cut solids, tubes, flats and other profiles in grades of material that range from hot and cold rolled steel, annealed tool steels, stainless, aluminum, brass, copper, synthetics and extrusions.

Cold sawing is a process similar to a milling process. In most cases, this, combined with the variable speed feature, gives a finished cut that does not require any secondary machining or de-burring.

Since milling spindle speeds are used in cold sawing, there are several things that are required to achieve quality results. The selection of the proper pitch (number of teeth) on the blade and the proper spindle speed for the type of material being cut are critical. Proper material clamping and a good quality coolant are also important.

Cold sawing has several advantages over band saws and abrasive saws. Besides the mill quality cut, cold saws have the ability to generate faster cutoff times than band saws. There are no sparks and excessive noises that are associated with abrasive cutoff saws. There is no work hardening of the workpiece.

Cold saws also offer the advantage of blades that can be re-sharpened until the diameter of the blade will no longer cut through the material. The vise allows for easy changeover to special clamping jaws for profiles and extrusions. Having a motor variable speed control enables the user to cut a wide range of materials.

2.0 SAFETY PRECAUTIONS

1. The operators of this machine must be qualified and well trained in the operation of this machine. The operators must be aware of the capacities and the proper use of this machine.
2. This manual is not intended to teach untrained personnel how to operate equipment.
3. **NEVER OPERATE THIS MACHINE WITH ANY OF THE PROTECTIVE GUARDS OR HOODS OPEN OR REMOVED!**
4. Wear the appropriate personal protective equipment. Safety glasses are required at all times when operating or observing this machine in operation.
5. Never place any part of your body into the path of the saw blade, material vises or shuttle cylinder.
6. Do not wear loose fitting clothing, gloves or jewelry when operating this machine.
7. All electrical connections shall be made by a qualified electrician. This machine must be grounded in accordance with the National Electric Code.
8. Disconnect the machine from the power source before performing maintenance or changing blades.
9. Strictly comply with all of the warning labels and decals on the machine. Never remove any of the labels. Promptly replace worn or damaged labels.

10. **Practice good housekeeping. Keep the area around the machine clean and dry. Do not obstruct the operators position by placing anything around the machine that would impede the operators access to any of the machines functions.**
11. **When sawing, always support long pieces and make sure that the material is properly clamped.**
12. **Keep the guards, as well as all other parts of the saw, in good working condition. Replace worn parts promptly.**
13. **Do not alter or modify this machine in any way without written permission from the manufacturer.**
14. **Set up a program of routine inspections and maintenance for this machine. Make all repairs and adjustments in accordance with the manufacturers recommendations.**

3.0 WARRANTY

Scotchman Industries, Inc. will, within 2 years of date of purchase, replace F.O.B. the factory or refund the purchase price for any goods which are defective in materials or workmanship, provided that the buyer returns the warranty registration card within thirty (30) days of purchase date and, at the sellers option, returns the defective goods, freight and delivery prepaid, to the seller, which shall be the buyers sole and exclusive remedy for defective goods.

Hydraulic and electrical components are subject to their respective manufacturers warranties.

This warranty does not apply to machines or components which have been altered, changed or modified in any way or subjected to abusive or abnormal use, inadequate maintenance or lubrication or subjected to use beyond the sellers recommended capacities and specifications.

In no event shall seller be liable for labor costs expended on such goods or consequential damages.

Seller shall not be liable to purchaser or any other person for loss or damage, directly or indirectly arising from the use of the goods or from any other cause.

No officer, employee or agent of the seller is authorized to make any oral representations or warranty of fitness or to waive any of the foregoing terms of sale and none shall be binding on the seller.

Any electrical changes made to the standard machine, to comply with local electrical codes, must be paid by the purchaser.

As we constantly strive to improve our products, we reserve the right to make changes without notification.

4.0 INSTALLATION AND SET-UP

⊠ **CAUTION: THIS SECTION DISCUSSES INSTALLATION AND SET-UP PROCEDURES. PLEASE READ ALL SECTIONS OF THIS MANUAL THOROUGHLY BEFORE OPERATING THIS MACHINE.**

4.1 PHYSICAL DIMENSIONS

SEE FIGURE 1 ON THE FOLLOWING PAGE.

	DIMENSIONS	INCHES	CM
A	HEIGHT	65	165
B	FLOOR TO VISE	38.5	98
C	BASE HEIGHT	35	89
D	WISE OPENING	3-5/8	9.2
E	WISE DEPTH	2-1/4	5.7
F	BASE WIDTH	61	155
G	BASE DEPTH	25	64
H	WIDTH	100	254
I	DEPTH	44	112
	WEIGHT	1,750 LB.	795 KG.





FIGURE 1

4.2 MACHINE INSTALLATION

SEE FIGURE 2 ON THE FOLLOWING PAGE.

This machine is shipped on a pallet and can be moved to the installation location by means of a forklift.

⊠ **CAUTION: THIS MACHINE IS TOP HEAVY AND MUST BE MOVED WITH CARE, ON HARD FLAT SURFACES ONLY.**

USE THE FOLLOWING STEPS TO INSTALL THE MACHINE:

1. Select a location for the machine that allows adequate room for any length of material that you may want to cut. Leave adequate space behind the machine and on either end, for set-up and maintenance.
 2. Lift the machine off of the shipping pallet, using a forklift.
 3. Place the machine in its final location and level it, using the leveling pads. For this machine to function properly, it is very important that it is level. Any supply tracks used with this machine must also be level and aligned with the vises on the machine.
 4. Install the shuttle cylinder on the machine.
- ⊠ **NOTE: MACHINES EQUIPPED WITH A DIGITAL READOUT WILL ALREADY HAVE THE CYLINDER INSTALLED.**
5. We strongly recommend that you anchor the machine and supply tracks to the floor, with the anchor plates provided with the machine.
 6. Connect the main air and electrical supply lines to the machine. To connect the air, slide the shuttle valve (I) down to the closed position and connect the incoming supply line. (DO NOT TURN THE AIR ON YET.) This machine requires a minimum of 90 PSI and may require up to 130 PSI, depending on your application. The electrical supply lines must be connected by a qualified electrician. The supply lines connect to the top of the main disconnect switch (J) located in the lower base cabinet. Make sure that your plant phase and voltage correspond to the phase and voltage of the machine before connecting the electrical supply.

⊠ **CAUTION: DO NOT POWER THE MACHINE UNTIL THE MACHINE INSTALLATION IS COMPLETE AND UNTIL YOU HAVE READ ALL OF THE SECTIONS OF THIS MANUAL!**





FIGURE 2

4.3 ELECTRICAL REQUIREMENTS

⊗ **CAUTION: TO PREVENT DAMAGE TO THE MACHINE AND DANGER TO THE OPERATOR, ALL ELECTRICAL CONNECTIONS MUST BE MADE BY A QUALIFIED ELECTRICIAN. THIS MACHINE OPERATES WITH LIQUID COOLANT AND MUST BE GROUNDED IN ACCORDANCE WITH NATIONAL ELECTRIC CODES.**

All machines are wired for three phase power. If the machine is not the same voltage as your plant voltage, you can purchase a transformer to either step up or down to the correct voltage for the machine. The other option is to change the voltage of the saw. To do that, it will be necessary to replace the VFD (Variable Frequency Drive), change the primary leads on the transformer and rewire the motor. And if equipped with optional flood coolant rewire the coolant pump. To ensure satisfactory performance, the supply voltage should be (+ or -) 10% of the motor voltage rating. Check the motor data tag for full load current requirement.

THE ELECTRICAL DIAGRAM FOR THIS MACHINE IS IN SECTION 14.0.

For supply lines ten feet (304 cm) or shorter, we recommend 12 gauge wire. For lines longer than ten feet (304 cm), we recommend 10 gauge wire. We do not recommend supply lines over twenty feet (609 cm) in length.

CPO-315-HFA-LT (11-177 RPM)		
<u>MOTOR VOLTAGE</u>	<u>FULL LOAD CURRENT</u>	<u>HORSEPOWER</u>
208	18	5
230	17.3	5
460	10	5

4.4 COOLANT SYSTEM

The CPO-315-HFA saw is equipped with a mist coolant system. A flood coolant system is an option for this saw.

The container for the coolant is located on the inside of the front door of the saw.

The coolant should be mixed in a ratio of one part coolant to seven parts water. We recommend using our P/N 075751 coolant (1 gallon) for most applications. This is also available in 5 gallon bucket as P/N 075752 and in a 55 gallon drum as P/N 075754. This coolant can be mixed stronger if needed.

When cutting alloy steels such as stainless steel, we recommend our special mix coolant designed for these applications: P/N 075756 in a 1 gallon jug and P/N 075757 in 5 gallon bucket.

We recommend pre-mixing the coolant before adding it to the saw.

FOR ADDITIONAL INFORMATION ON AVAILABLE COOLANTS, SEE SECTION 12.2.

5.0 MACHINE START-UP

Before starting this machine, take the time to review the operator's manual thoroughly, to familiarize yourself with all of the functions of the machine.

We strongly urge you to follow OSHA directive CFR-1910.147 (effective 09-09-90) regarding lock-out, tag-out procedures. Keep in mind that the directive refers to all hazardous energy sources, not just electrical.

The air supply must also be disconnected and locked or tagged.

Do not install a blade on the saw until after it has been powered and cycled several times.

Once the machine has been powered, check the rotation of the spindle. There is an arrow on the guard showing the proper rotation. If the rotation is not correct, the electrician will have to switch two of the three motor wires.

5.1 CONTROL PANEL FUNCTIONS

The following section gives a brief description of each of the control panel switches and buttons.

Before powering the machine, please familiarize yourself with the location and the function of each of these items. SECTION 7.0 will describe how to set the machine up for an operation.

REFER TO FIGURE 3 BELOW.




FIGURE 3

5.1A MAIN POWER SWITCH

This is the main power disconnect switch for the machine and it should be locked or tagged in the OFF position any time that maintenance or service work is being performed. Maintenance or service work on the electrical controls must be performed by qualified personnel. This switch must be in the ON position to operate any of the other control panel functions.

There is a red power indicator light (O) on the control panel. This light indicates that this switch is in the ON position.

⊠ CAUTION: THIS SWITCH DOES NOT DISCONNECT THE AIR SUPPLY TO THE MACHINE. ANY TIME THAT MAINTENANCE OR SERVICE WORK IS PERFORMED ON THE MACHINE, THE AIR SUPPLY MUST ALSO BE DISCONNECTED AND TAGGED OR LOCKED OUT.

5.1B MOTOR CONTROL SWITCH

This switch is used to turn the saw motor on.

5.1C POWER UP SWITCH

This switch energizes the system for the rest of the control panel functions. This switch will also start the saw motor. The motor will not start unless the MAIN POWER switch (A) is on and the AUTOMATIC/ MANUAL SWITCH (I) is in the manual position. The MOTOR SWITCH (B) must be in the ON position for the saw motor to start.

5.1D EMERGENCY STOP SWITCH

This switch stops the saw motor and allows the head to return to the up position. The emergency stop switch does not release the material vise or the air pressure. Once this switch has been used, the operator must restart the machine in the manual position and go through the startup procedure again.

For complete instructions on changing bars of material, REFER TO SECTION 7.0.

5.1E HEAD UP

This button is used to abort a cut in mid cycle when the AUTOMATIC/MANUAL SWITCH is in the MANUAL position. This button is inoperable when the machine is in the AUTOMATIC position.

5.1F HEAD DOWN

This button is also used to set the overall stroke of the machine and to make manual cuts.

5.1G HITCH SELECTOR

This switch is used to select the number of hitches the shuttle vise makes before the saw makes a cut.

POSITION 1 is for parts from 0 to thirty inches in length. POSITION 2 is for parts from thirty to sixty inches. POSITION 3 is for parts from sixty to ninety inches.

5.1H CYCLE/START BUTTON

This button starts the machine cycle. The CYCLE/START button is used to make trim cuts and set-up cuts prior to starting the automatic operation. It is also used to start the automatic operation once all of the test cuts are done.

5.1I AUTOMATIC/MANUAL SWITCH

This switch must be in the MANUAL position to start the machine, to make trim cuts and to set the product lengths. After the machine has been set up and sample cuts have been made, this switch is moved to the AUTOMATIC position. Any time that the saw is in the AUTOMATIC position, this switch can be turned to the MANUAL position. When it is turned to the MANUAL position, the machine will complete the cycle it's on and stop when the head reaches the up position. The saw motor will continue to run when this switch is used to stop the automatic operation of the machine. When this switch is in the AUTOMATIC position and the machine runs out of product, the operator must reset the machine's operation. For instructions on changing bars of material, REFER TO SECTION 7.0. When this switch is used to stop the automatic operation, you can make manual cuts as needed by depressing the CYCLE button (H). The machine will shuttle and cut one part. This can be done as many times as necessary.

You can then switch the AUTOMATIC/MANUAL SWITCH to the AUTOMATIC position and press the cycle button again. The machine will continue with the automatic operation until the part count is complete or the machine is out of material.

5.1J TRIM/TEST

This button is used to do first part cuts prior to running the machine in the automatic position. With the AUTO/MANUAL switch in the MANUAL position, press the TRIM/TEST button (J) and then, press the CYCLE button (H). The saw will trim and then cut one part and return to the up position. Make whatever adjustments that you need to and depress the CYCLE button (H) again and the saw will cut one more test piece. After you are satisfied with all of the settings, place the AUTO/MANUAL switch (I) in the AUTOMATIC position and press the CYCLE button again. The saw will start the automatic operation.

5.1K COOLANT PUMP SWITCH

This switch starts the machine's coolant pump.

5.1L VARIABLE MOTOR SPEED CONTROL

This switch is one of the most important standard features on this machine. This switch gives you a wide range of cutting speeds. The range is from 11 RPM to 177 RPM. With this feature, you are able to match the blade speed to the material, which greatly increases blade life and reduces vibrations. When this switch is in the 50 percent position, the machine runs at 83 RPM. With the switch at the 0 percent position, the RPM'S will be 11 and with the switch at the 100 percent position, the RPM'S will be 177.

5.1M COUNTER

The Parts Counter is programmed at the factory to count up. If you want to set the counter to count down, please contact the factory. To enter a pre-set value in the counter, press any of the white keys numbered 1 to 5. The pre-set value will appear on the screen. Use the white keys to set the total number of pieces that you want to cut. After a three second delay, the pre-set value screen will disappear. The counter will then display the number of pieces cut as the saw runs. When the value on the screen reaches the pre-set value, the machine will stop. If you press the red button, the count value displayed on the screen will be zeroed out. The reset button does not erase the pre-set value. To change the pre-set value, press any white button and the pre-set value will appear on the screen. For the machine to run in the automatic mode, there must be a pre-set value on the counter.

5.1N FEED RATE CONTROL

This valve controls the down feed rate of the saw head and is used in the set-up of the up and down stroke control of the saw head. To adjust the down feed cutting rate of the head, turn the control all the way to the right (clockwise) and then, open it one turn. The down feed rate is set by sound. Start with a slow rate and gradually increase it until the blade chatters, then back it off slightly. Selecting the proper blade and the condition of the blade will effect the down cutting rate dramatically. There is also a down feed regulator, located on the machine, that provides constant down pressure on the material.

5.10 POWER INDICATOR LIGHT

This light indicates that the main switch (A) is on and that there is power to the control panel.

6.0 MACHINE OPERATION

6.1 SELECTING THE PROPER CUTTING SPEED

In cold sawing, there is no such thing as a general purpose blade. To achieve the best results from your saw, proper blade selection is important. Each saw is shipped with a pitch (number of teeth) calculator, which will help to determine the proper blade for your application.

When sawing flat stock or rectangular solid sections, determine the thickest section that will be cut and use the equivalent square size on the pitch calculator to determine the proper blade.

The CPO-315-HFA is designed to use a maximum 12-1/2 inch (315mm) diameter blade. 10-3/4 inch blades are also available for this machine.

The chart below gives the surface feet per minute for the various spindle RPMS:


<u>BLADE DIAMETER</u>		<u>SURFACE FEET PER MINUTE</u>		
INCH	MM	11	88	176 - BLADE RPMS
10-3/4	275	31	249	499 - SFM
12-1/2	315	36	286	572 - SFM

The proper blade speed is also important. The High speed (176 RPM) is recommended for thin walled tubes and nonferrous tubes and profiles. Some materials will require test cuts at both speeds to determine the best speed for the application. The Low speed, 11 RPM, is recommended for solid sections of mild steel and alloy tubes.

**FOR BEST RESULTS, USE ONLY SCOTCHMAN COLD
SAW BLADES AND COOLANT. SEND YOUR BLADES
BACK TO THE FACTORY FOR PROFESSIONAL
RESHARPENING ON MODERN CNC EQUIPMENT.**

WWW.SCOTCHMAN.COM

Metal Fabricating Solutions



6.2 BLADE INSTALLATION

SEE FIGURE 4 BELOW.




FIGURE 4

- ⊗ **CAUTION: USE ONLY HIGH SPEED STEEL BLADES DESIGNED FOR THIS MACHINE. DO NOT MODIFY ANY BLADE TO FIT THIS MACHINE. DO NOT USE BLADES DESIGNED FOR THIS MACHINE ON ANY OTHER EQUIPMENT. THE MAXIMUM RPM'S FOR THESE BLADES ARE 600 FOR THE 12-1/2" AND 700 FOR THE 10-3/4".**

The CPO-315-HFA saw is designed to use a maximum 12-1/2 inch (315mm) diameter blade. The arbor size is 40mm with four 12mm pins spaced at 65mm.

BEFORE INSTALLING THE BLADE, make sure that the power to the machine is off.

USE THE FOLLOWING STEPS TO INSTALL A BLADE:

An 8mm hex key wrench (D), shipped with each machine, is required to change blades.

1. Raise the movable hood guard to the open position.
2. Release the upper stroke control stop (H) and allow the head to travel to its full up position.
3. Back off the blade guide bolts (G), if they are being used, and slide them out to the end of the slots.
4. Remove the blade bolt (B) and the blade flange (C).
5. Check the blade flange, the blade and the saw spindle for any chips or nicks that will affect the way the blade seats.
6. Install the blade. Make sure that the pin holes in the blade line up to the holes in the spindle.
7. Replace the blade flange (C) and start the bolt (B) into the spindle.
8. Before locking the blade in position, the back lash must be taken up. To take up the back lash, rotate the bottom of the blade toward you until it seats against the drive pins.

- ⊗ **CAUTION: THE BLADES ARE VERY SHARP AND CARE MUST BE TAKEN WHEN REMOVING THE BACK LASH. DO NOT GRIP THE CUTTING EDGE OF THE BLADE BARE HANDED. THE BACK LASH MUST BE TAKEN UP EVERY TIME A BLADE IS CHANGED.**













9. After taking up the back lash, tighten the blade bolt (B).

- 10. Adjust the blade guide bolts (G), if required. These guides are required only when the blade has a small amount of deflection in it or when a very exact cut is required. Adjust the inside, or right hand bolt, first. The bolt should be adjusted up to where it just touches the blade as close to the teeth as possible and lock the retaining nut. Do not adjust the bolt to where it deflects the blade. Over adjustment of the guide bolt will cause the blade not to run true and will cause excessive wear. After the inside bolt is adjusted, move the outside bolt to where it is straight across from the inside one. Adjust the outside bolt up to where it just touches the blade and then, lock the retaining nut.**
- 11. Reset the upper stroke control and return the movable hood guard to the down position.**
- 12. Break in the saw blade. The teeth on new or re-sharpened blades have a very sharp edge and should be fed through the first three or four cuts, very slowly, before starting normal cutting. Besides taking up the back lash and breaking in the blade, it is very important to keep the blade flange, the spindle and the blade clean and free from nicks. Failure to do these things will result in broken or damaged blades.**

6.3 SAW CAPACITIES

SEE FIGURE 5 BELOW.


Figure 5 below is a chart showing the maximum capacities of this machine in various materials.

CAPACITIES WITH MAXIMUM DIAMETER BLADES 315 MM		HFA 90° ONLY 	RFA/ST 90° ONLY 	RFA/ST BUNDLE FEED 
	INCHES MM	Ø3-1/2 Ø89	Ø3 Ø76	Ø3 Ø76
	INCHES MM	3-1/8 X 3-1/8 79 X 79	2-1/2 X 2-1/2 63 X 63	2-1/2 X 2-1/2 63 X 63
	INCHES MM	3-1/8 X 3-1/8 79 X 79	2-1/2 X 2-1/2 63 X 63	N/A
	INCHES MM	3-1/8 X 3-1/8 79 X 79	2-1/2 X 2-1/2 63 X 63	N/A
	INCHES MM	3-1/2 X 2-3/4 89 X 70	3 X 2-1/2 76 X 63	3 X 2-1/2 76 X 63
 FERROUS	INCHES MM	Ø1-3/4 Ø44	Ø1-3/4 Ø44	Ø1-3/4 Ø44
 FERROUS	INCHES MM	1-1/2 X 1-1/2 38 X 38	1-1/2 X 1-1/2 38 X 38	1-1/2 X 1-1/2 38 X 38
 NF	INCHES MM	Ø3-1/2 Ø89	Ø3 Ø76	Ø3 Ø76
 NF	INCHES MM	3-1/8 X 3-1/8 79 X 79	2-1/2 X 2-1/2 63 X 63	2-1/2 X 2-1/2 63 X 63

03/21

#047200

FIGURE 5



The following are set-up and maintenance instructions for the material main vise.

- 1. Make sure that the filter/lubricating device (A) is full of oil.**
- ⊗ NOTE: Use a quality (ISO 22) air line lubricant designed for automatic oilers.**
- 2. Slide the shuttle valve (F) on the filter/lubricator device down to the closed position.**
- 3. Connect the air supply to the shuttle valve. Make sure that the vise is clear and that the head is in the UP position.**
- 4. Slide the shuttle valve up to open the valve. Whenever the shuttle valve is closed, it bleeds the air pressure out of the system automatically.**
- 5. Adjust the air pressure regulator (C). 90 PSI (6.2 BAR) is the minimum operating pressure. 130 PSI (9 BAR) is the maximum.**
- 6. The vise is activated by the top proximity switch on the saw head.**
- 7. The lubricating device (A) should release one drop of oil every 5 to 10 cycles. On top of the lubricating device is a clear plastic dome with a small tube inside. The oil should drop out of the tube. The lubricating device is adjusted by turning the knob (B) on the top of the lubricator.**
- 8. To add oil to the lubricating device, disconnect the air supply and remove the plastic bowl. The bowl is threaded and is removed by turning the threaded collar (G). Fill the bowl approximately 3/4 full of oil designed for air lubricators and screw it back onto the lubricator.**

TO ADJUST THE VISE TO THE SIZE OF MATERIAL BEING CUT:

- 1. Open the vise, using the positioning handle (E), and place the material in the vise.**
- 2. Crank the vise closed to within approximately 1/8 of an inch (3mm) from the material.**
The power vise has approximately 1/4 of an inch (6mm) of stroke.
Proper clamping is very important and special jaws may be required for some materials.

FOR MORE INFORMATION CONTACT YOUR LOCAL DEALER OR THE FACTORY.

MODEL CPO-315-HFA-5HP



- FULLY AUTOMATIC CYCLE
- PUSH BUTTON CONTROLS ACTUATE THE COMPLETE CYCLE
- INTERLOCKING SAFETY HOOD
- EMERGENCY STOP BUTTON
- CLAMPING BOTH SIDES OF BLADE - HIGHEST QUALITY, BURR-FREE CUTS
- BLADE GUIDES FOR ACCURATE TOLERANCES (FERROUS MODEL)
- MIST COOLANT LUBRICATION SYSTEM
- ADJUSTABLE STROKE CONTROL ON THE SAW HEAD
- ADJUSTABLE DOWN FEED CONTROL ON THE SAW HEAD FOR FEED RATE

6.5 SHUTTLE VISE & CYLINDER

REFER TO FIGURE 6 ON PAGE 22.

- ⊗ **CAUTION: ALWAYS DISCONNECT THE AIR SUPPLY BEFORE REMOVING THE FILLER PLUG FROM THE RESERVOIR. IF THE FILLER PLUG IS REMOVED WHILE THE MACHINE IS CONNECTED TO AIR PRESSURE, THE FLUID IN THE TANK WILL BE PURGED THROUGH THE OPENING UNDER PRESSURE.**

The shuttle vise reservoir is located behind the control panel. The fluid level in should be 1-1/2 inches below the top of the reservoir when the shuttle cylinder is completely extended, all the way to the left, up against the material main vise. Do not add oil if the cylinder is in any other position. Over filling the reservoir will cause hydraulic oil to be forced into the air system of the machine.

- ⊗ **NOTE: Use a SAE 10W (ISO 32) non-foaming hydraulic oil, such as Mobil DTE 10 or equivalent**

The following are set-up and maintenance instructions for the shuttle assembly.

1. Steps 1 through 8 are the same for the shuttle vise as they are for the material vise.

TO ADJUST THE VISE TO THE SIZE OF MATERIAL BEING CUT:

2. Open the vise, using the positioning handle (D), and place the material in the vise.
3. Crank the vise closed to within approximately 1/8 of an inch (3mm) from the material.

The shuttle vise has approximately 1/4 of an inch (6mm) of stroke. Proper clamping is very important and special jaws may be required for some materials. The speed of the shuttle cylinder is controlled by the flow control valve (H) on the bottom of the reservoir. Since the shuttle system is a positive stop type, feeding heavier materials too fast will adversely affect the tolerance of the length of the part. The feed rate is preset and should not need to be adjusted. If you do decide to adjust it, make the adjustments in small increments.

6.6 POWER DOWN FEED

REFER TO FIGURE 8 BELOW.




FIGURE 8

⊗ CAUTION: ALWAYS DISCONNECT THE AIR SUPPLY BEFORE REMOVING THE FILLER PLUG FROM THE RESERVOIR. IF THE FILLER PLUG IS REMOVED WHILE THE MACHINE IS CONNECTED TO AIR PRESSURE, THE FLUID IN THE TANK WILL BE PURGED THROUGH THE OPENING UNDER PRESSURE.

- 1. BEFORE POWERING THE SAW, check the oil level in the reservoir (A). It should be approximately 2-1/2 inches below the top of the reservoir when the saw head is in the UP position.**

Over filling the reservoir will cause hydraulic oil to be forced into the air system. The recommended oil is a 10 WT., non-foaming, hydraulic oil such as Cenex (CEN-LUBE RO AW 150).

- 2. Slide the shuttle valve (C) to its CLOSED position and connect the air supply.**
- 3. Slide the shuttle valve to its OPEN position and shut the flow control valve (B) off. Then, open it one turn.**
- 4. The down feed rate is adjusted using the flow control valve (B). The down feed rate should be set during the setup of an operation while the AUTOMATIC/MANUAL switch is in the MANUAL position. The setting of the down feed rate is done by sound. Slowly adjust the rate as the saw makes a cut. Once the blade starts to chatter or the saw starts to load up, back the rate off by 1/4 of a turn.**

Many things, including the type of material being cut, the blade RPM and the condition of the blade, will affect the down feed rate.

6.7 MATERIAL CLAMPING

All work pieces must be clamped securely in the vise. Any slippage of the material can result in broken or damaged blades. The material should be clamped so that the contact surface between the material and the blade is as small as possible. For this reason, when cutting flat stock material, we recommend standing it up and cutting it through the thinnest section, whenever possible. We also recommend cutting square tubing through the diagonal section and angle iron with the web up. Some thin walled round sections and profiles will require special jaws to hold them.

FOR EXAMPLES, SEE FIGURE 7 ON PAGE 24.

6.8 STROKE CONTROL ADJUSTMENT

SEE FIGURE 9 ON THE FOLLOWING PAGE.

TO ADJUST THE UP AND DOWN STROKE OF THE SAW HEAD, USE THE FOLLOWING STEPS:

1. With the machine's power off, raise the hood of the saw.
2. Using a 17mm wrench, loosen the bolt (A) on the lower stroke control (B) and let the stroke control rest at the bottom of the slot.
3. Place a piece of the material that you are going to cut in the saw vise and manually clamp it in a position so that the saw blade will not contact the material when the head comes down.
4. Close the hood. The saw will not run with the hood open.
5. Make sure that the motor switch (D) is in the OFF position so that the saw blade does not turn while performing this setup.
6. Power the saw and press the HEAD DOWN button (E).
7. When the blade has passed the material in the vise by approximately 1/8 of an inch (3mm), stop the head movement by turning off the flow control valve (F) and turn off the air pressure by sliding the shuttle valve (G) down.
8. Turn the power off. Raise the hood and bring the lower stroke control (B) up to the head stop and lock it in place.
9. Bring the upper stroke control (C) down to the head stop and lock it in place.
10. Turn the air back on by moving the shuttle valve (G) up and open the flow control valve (F) one turn.
11. Loosen the bolt (A) on the upper stroke control (C) and allow the head to move slowly up until the blade is approximately 1/8 of an inch (3mm) above the material in the vise. Tighten the bolt in the upper stroke control.




FIGURE 9

6.9 COUNTER SET-UP

REFER TO FIGURE 10 BELOW.




FIGURE 10

A. PARTS COUNTER

The Parts Counter is programmed at the factory to count up. If you want to set the counter to count down, please contact the factory. To enter a pre-set value in the counter, press any of the white keys numbered 1 to 5. The pre-set value will appear on the screen. Use the white keys to set the total number of pieces that you want to cut. After a three second delay, the pre-set value screen will disappear. The counter will then display the number of pieces cut as the saw runs. When the value on the screen reaches the pre-set value, the machine will stop. If you press the red button, the count value displayed on the screen will be zeroed out. The reset button does not erase the pre-set value. To change the pre-set value, press any white button and the pre-set value will appear on the screen. For the machine to run in the automatic mode, there must be a pre-set value on the counter.

7.0 MACHINE AUTOMATIC OPERATION (SET-UP)

REFER TO FIGURE 11 BELOW.

The following instructions are to set up a job for automatic operation. Make sure that you are familiar with the functions of all of the switches and buttons before proceeding.




FIGURE 11

1. Set the shuttle vise indicator to the desired length by loosening the moving stop (M) and move it to the length desired on the scale and re-tighten it. These bolts must be locked down tight, to prevent the length setting from changing while the saw is in operation. Check them periodically throughout the day.
 2. Place the HITCH FEED switch (G) in the desired position.
 3. Adjust the shuttle vise and material vise for the size of material. Adjust the vises up to the material, allowing approximately 1/8 of an inch (3mm) clearance for the throw of the cylinder.
 4. Set the upper and lower stroke of the saw head. For instructions, REFER TO SECTION 6.8.
 5. Place the main power switch (A) in the ON position and the motor control switch (B) in the ON position.
 6. Place the AUTO/MANUAL switch (I) in the MANUAL position and pull the EMERGENCY STOP switch (D) out.
 7. Place the material to be cut in the material vise jaws so that 1/4 to 1/2 inch extends past the blade slot.
 8. Press the POWER UP button (C).
 9. Press the TRIM/TEST button (J) and the CYCLE button (H). The machine will make a trim and a test cut. Adjust the down feed rate of the head, using the flow control valve (N) while it is making the first cut.
 10. Check the accuracy of the first part and make any adjustments required. The fine adjustment knob (O) will change the length of the part by 1.5 thousandths of an inch per increment.
 11. Press the CYCLE button again and the machine will make another test cut.
 12. Set the counter (P) to the desired number of pieces. For instructions, REFER TO SECTION 6.9.
 13. After you have made all of the fine adjustments, place the AUTO/MANUAL switch in the AUTO position and press the CYCLE button again. The machine will start the automatic operation and continue until the counter reaches the set quantity or the machine runs out of material.
- ➡ **IMPORTANT:** When the machine has finished a bar of material, you have to reset the machine before continuing with the automatic operation. **TO RESET THE MACHINE:**
1. Load the new bar in the machine with approximately 1/2 inch extending past the blade slot in the material vise.
 2. Turn the AUTOMATIC/MANUAL switch (I) to the MANUAL position.
 3. Push the TRIM/TEST button (J) and then the CYCLE button (H). The saw will make one trim cut and one test cut.
 4. Place the AUTOMATIC/MANUAL switch (I) in the AUTOMATIC position and press the CYCLE button (H) and the saw will continue with the automatic operation.
- ⊠ **CAUTION:** FAILURE TO FOLLOW THE ABOVE PROCEDURE EVERY TIME THAT A NEW BAR IS LOADED WILL CAUSE THE MACHINE TO MALFUNCTION.

8.0 MAINTENANCE

8.1 LUBRICATION

SEE FIGURE 12 BELOW.

Grease the head pivot pin (C) and the spindle shaft with a high pressure, high temperature, bearing grease daily. Apply oil to the shuttle vise guide shafts daily.

Clean the chips out of the vise at least once a day, more often if needed. Apply penetrating oil to the spindle and guide pins. Clear the chips with a brush or similar device. DO NOT use compressed air.

Check the oil level in the air lubricator device daily.




FIGURE 12

8.2 CUTTING OILS AND LUBRICANTS

SECTION 12.2 lists Scotchman.s parts numbers for cutting oils and lubricants. Using high quality lubricants and oils will greatly increase the life of this equipment.

We recommend using only pure, synthetic, water soluble, cutting oil for coolant.

For the saw head, use a non-EP additive ISO-460 gear oil specified for worm gears. Oils containing EP additives may degrade or damage bronze gears and must be avoided. Mobile 600WSuper Cylinder Oil is highly recommended and available from the factory under P/N 075758.

For the power down feed reservoir, use a SAE 10W (ISO 32) non-foaming hydraulic oil, such as Mobil DTE 10 or equivalent

8.3 SCHEDULED MAINTENANCE

A program of scheduled maintenance should be set up and documented according to your application and the frequency you use this machine. The following is a list of some important things that should be included in a scheduled maintenance program.

1. EVERY 250 HOURS OR 3 MONTHS:

If your saw is equipped with the optional flood coolant system, drain the coolant reservoir and flush it. Refill the coolant reservoir with new coolant. Capacity is 8 gallons. This will extend the life of the coolant pump considerably. Check the level of the hydraulic fluid in the power down feed and shuttle cylinder reservoirs.

⊗ **CAUTION: ALWAYS DISCONNECT THE AIR SUPPLY BEFORE REMOVING THE FILLER PLUG FROM THE RESERVOIR. IF THE FILLER PLUG IS REMOVED WHILE THE MACHINE IS CONNECTED TO AIR PRESSURE, THE FLUID IN THE TANK WILL BE PURGED THROUGH THE OPENING UNDER PRESSURE.**

2. EVERY 750 HOURS OR 6 MONTHS:

Drain the gear oil from the saw head and flush with a petroleum product. Refill the saw head with use a non-EP additive ISO-460 gear oil specified for worm gears. Mobile 600W Super Cylinder Oil is highly recommended and available from the factory under P/N 075758. Check the condition of the pivot pins on the head and on the guard. Check the complete saw for loose connections in the electrical and air systems.

Since every application is different, each user must design and implement a scheduled maintenance program that fits his applications.

8.4 GEAR REPLACEMENT (SAW HEAD)

REFER TO FIGURE 13 BELOW.





FIGURE 13

1. **Remove the drain plug (P) from the head casting and allow the fluid to drain.**
2. **Remove the motor from the head.**
3. **Remove the four bolts (J) from the bearing retainer (F).**
4. **Remove the worm shaft assembly (A thru K). The worm shaft has a 10mm threaded hole in the end of it for a slide hammer. This is the preferred method of removing the shaft. If you do not have a slide hammer, the shaft can be removed by driving it out with a brass drift pin. See NOTE in FIGURE 13.**
5. **Inspect the worm shaft, drive gear and bearings for wear.**
6. **After the worm shaft has been removed, remove the three bolts (EE) from the bearing housing (Y).**
7. **Remove the spindle shaft assembly (U thru II) with a slide hammer. This shaft can also be removed by driving it out of the head casting with a brass drift pin. See NOTE in FIGURE 13.**
8. **Remove the snap ring (FF).**
9. **The brass worm gear (U) can now be pressed off of the shaft.**
10. **Check the condition of the bearings (A, C, E, & W) and seals (X & GG) before re-assembling the head.**
11. **Check the condition of the key (HH) and the key-way in the gear and spindle shaft.**

SEE FIGURE 14 BELOW.



1. **Disconnect the machines power and the air supply.**
2. **Remove the vise guard (X) and the spring (Y) and ball (HH).**
3. **Remove the bolts (A & B) and the retainer (D).**
4. **Remove the clevis pin (F) and remove the clevis (E) and the forks (CC).**
5. **The spindle can now be removed from the machine.**
6. **If the spindle is locked up in the machine, remove the bolts (II) and the side plate (GG).**
7. **The vise block (L) and the spindle can now be removed as one piece.**
8. **Install the new spindle and reassemble the vise, reversing the above steps.**

8.6 SEAL REPLACEMENT (MAIN VISE)

SEE FIGURE 14 ON THE PRECEDING PAGE.

1. **Make sure that the power and air supply to the machine are both off.**
2. **Remove the bolts (A & B) and the retainer (D).**
3. **Remove the clevis pin (F) and the cylinder clevis (E) and the forks (CC).**
4. **Remove the two lower bolts (C) and remove the cylinder (H) from the machine.**
5. **Place the cylinder in a vise and remove the snap ring from the front of the cylinder.**
6. **Pull the cylinder apart and remove all of the old seals. Check the end casting, cylinder tube and piston for nicks or scratches.**
7. **Install the new seals and reassemble the vise, reversing the above procedures.**

8.7 SHUTTLE VISE MAINTENANCE

SEE FIGURE 15 BELOW.




FIGURE 15

TO REPLACE THE VISE SPINDLE:

- 1. Remove the jam nut (GG), the set screw (H), the spring (FF) and the ball (G).**
- 2. Remove the jam nut (A) and the boss (B) from the end of the spindle.**
- 3. Disconnect the air lines and the proximity switch from the cylinder. The air connections on the cylinder are snap connectors. To release the air connections, push the collar around the hose into the fitting and pull the hose out. To reconnect the lines, simply push the air line into the fitting as far as it will go easily.**
- 4. Remove the four bolts (Z) from the cylinder end plate and remove the cylinder assembly from the machine.**
- 5. Slide the vise spindle (K) and vise block (L) off of the machine and replace either part, as needed.**
- 6. Reassemble the vise, reversing the above steps.**

IF YOU NEED TO REPLACE THE SEALS IN THE AIR CYLINDER:

- 1. After step number 4 above, clamp the end plate (D) in a vise and remove the four bolts (PP).**
- 2. Slide the end plate (AA) off and remove the piston (CC) and the cylinder tube (C).**
- 3. Replace the seals and reassemble, reversing the above steps.**

8.8 COOLANT PUMP MAINTENANCE

(OPTINAL FLOOD COOLANT)

SEE FIGURE 16 BELOW.




FIGURE 16

IF YOUR COOLANT PUMP IS LEAKING OR LACKS POWER, USE THE FOLLOWING STEPS:

NOTE: WE RECOMMEND REPLACING THE PUMP SEAL (D) P/N 060151 ANYTIME THE PUMP IS DISMANTLED.

FOR PART IDENTIFICATION, SEE THE FOLLOWING PAGE

- 1. Make sure that the power to the machine is off.**
- 2. Remove the four bolts (J) and remove the pump from the machine.**
- 3. Remove the coolant line (H) and the fittings (K). Clean any sludge out of the line and fittings.**
- 4. Remove the three bolts (F) and remove the end plate (C).**
- 5. Remove the screw (E), seal (D) and the impeller (B) from the pump.**
- 6. Clean the sludge out of the impeller, end cap and passage way from the bottom of the pump to the outlet port.**
- 7. Reassemble the pump, reversing the above steps.**
- 8. Clean out the reservoir and fill with new coolant. We recommend our P/N 075751 saw coolant mixed in a ratio of one part coolant to seven parts water. The capacity is 8 gallons.**

9.0 OPTIONAL EQUIPMENT

9.1 SPECIAL VISE JAWS

Special vise jaws for holding thin wall round tubes, profiles and bundles are available on a made-to-order basis. For prices and delivery on special jaws, contact your local dealer or the factory.

FOR MORE INFORMATION CONTACT YOUR LOCAL DEALER OR THE FACTORY.

9.2 OPTIONAL IN FEED SUPPLY TRACKS

A ten foot roller supply track, that can be installed on the input side of the saw to support longer pieces of material, is an available option for this saw.


The supply tracks can also be bolted end to end, to supply longer tracks, if needed.

SEE FIGURE 17 ON THE FOLLOWING PAGE.

1. What is shown is our P/N 029242 - 10' ROLLER CONVEYER W/LEGS that is fully assembled with our optional P/N 076938 - 13" GUIDE ASSEMBLY mounted to it.
2. The conveyors can be bolted together to make longer lengths if needed.
3. Adjust the conveyor so that the rollers are at the same level as the bed of the material vise on the saw. The conveyor height is adjusted via the slots in the legs.
4. For additional stability, we strongly recommend anchoring the conveyor to the floor.
5. The vertical rollers on the Guide Assembly are adjustable for width and can be adjusted to keep the material toward the front or back of the conveyor.
6. Several Guide Assemblies can be mounted to the conveyor if needed.

EXPLODED VIEW

DETAIL VIEW



076938
13" GUIDE
ASSEMBLY

029242 - 10' ROLLER
CONVEYER W/LEGS

FIGURE 17

10.0 TROUBLE SHOOTING GUIDE

10.1 ELECTRICAL TROUBLE SHOOTING

- 1. THE MOTOR WILL NOT RUN.**
 - A.** The main disconnect switch in the base cabinet must be on and the emergency stop switch must be pulled out.
 - B.** The motor switch must be in the ON position to start the saw motor.
 - C.** The MANUAL/AUTO switch must be in the MANUAL position to start the machine.
 - D.** Also, check the supply voltage to the saw to make sure that it is the same as the motor voltage. If the supply voltage is correct and the switch energizes and the motor still will not run, contact your dealer or the factory.
 - E.** The saw hood must be closed to start the motor.
- 2. THE SAW MOTOR RUNS BUT DOES NOT HAVE ADEQUATE POWER.**
 - A.** Make sure that the supply voltage and phase correspond to the saw motor's voltage and phase.
 - B.** Disconnect the machine from the power source and check for any loose or disconnected wires.
 - C.** The supply lines to the machine must be of adequate size to handle the load.
FOR RECOMMENDED SIZES AND LENGTHS, SEE SECTION 4.3.
 - D.** The worm gears in the head may be damaged. With the power to the machine disconnected, check the blade spindle for any free travel. If free play is present, drain the oil from the head and remove the motor. Check both worm gears for wear and replace, if necessary. We recommend replacing the worm gears as a set, if either shows wear.
FOR REPLACEMENT INSTRUCTIONS, SEE SECTION 8.4.
- 3. THE MACHINE WILL NOT RUN IN THE AUTOMATIC MODE.**
 - A.** The counter must have a pre-set quantity displayed. If the counter reads zero, the machine will not run in the automatic mode.
 - B.** There must be material in the shuttle vise and the vise must be adjusted to the material.
 - C.** If the machine has reached the end of a bar, you need to reset the machine before starting the automatic operation again. REFER TO SECTION 7.0.

10.2 BREAKAGE OR EXCESSIVE DULLING OF BLADES

- 1.** Select the proper blade and spindle speed for the material being cut.
FOR RECOMMENDATIONS, REFER TO SECTION 6.1.
- 2.** Always break in the blade before you start normal cutting.
- 3.** Do not apply excessive down pressure on the workpiece. Excessive down pressure will cause the teeth to remove too large of a chip, resulting in premature dulling or breakage.
- 4.** Use a good quality, synthetic coolant and maintain the proper ratio of coolant to water, as recommended in SECTION 4.4.

5. Have your blades re-sharpened by someone who has the right equipment for circular cold saw blades. Improper re-sharpening is one of the most common problems encountered in cold sawing.
6. Keep the blade flange, the face of the blade spindle and the blade clean and free from nicks. Any contamination or nicks on the flange, spindle or the blade will cause the blade to run out of alignment.
7. Always remove the back lash when installing a blade. For instructions, REFER TO SECTION 6.2. Also, check the condition of the drive pins when replacing the blade. If the drive pins are broken or worn, replace them.
8. Any of the above problems may cause a condition known as pick-up. Pick-up is caused when small pieces of the material being cut adhere themselves to the blade. When pick-up is present, you will notice a jerking or jumping motion in the saw head while cutting. This is caused by the blade being pinched as it goes through the material where the pickup is present. Pick-up can be removed by using a fine honing stone or a very fine file. When removing pick-up, care must be taken not to remove any part of the blade. After the pick-up has been removed, review the above items to determine what caused the problem.

10.3 PART LENGTH NOT CONSISTENT

1. Check your air pressure. This machine requires a minimum of 90 pounds of pressure to function properly. When cutting solid materials, the pressure may have to be set as high as 130 PSI to prevent the material from slipping in the jaws.
2. The bolts in the adjustable stop may not be tight enough, allowing the stop to move.
3. The main vise or shuttle vise may be adjusted too tight, causing the material to drag or bind before the vise is seated against the stop.
4. Check for chip build-up between the main vise and the shuttle vise.

10.4 FLOOD COOLANT SYSTEM (OPTIONAL)

1. IF THE COOLANT WILL NOT FLOW:
 - A. Make sure that the coolant switch on the control panel is on.
 - B. Check the wiring connections to the pump and make sure that the pump is running.
 - C. Check the level of the coolant in the reservoir. If there is less than three inches of coolant in the reservoir, the pump may not work.
 - D. Check the reservoir for contamination or sludge buildup that may be blocking the inlet.
 - E. Remove the coolant line from the guard and make sure that it is clear. Also, make sure that the valve on the guard is open.
 2. IF THE COOLANT PUMP IS LEAKING:
 - A. Check the connections on the coolant lines.
 - B. If the pump itself is leaking, there is a seal kit available.
- FOR PART NUMBERS, SEE SECTION 11.13.**

10.5 PLC TROUBLESHOOTING

The PLC on this machine has a readable screen on it that can be used to help diagnose most problems that may be encountered with the machine. The main controller (A) has 8 inputs (B) labeled I1 to I8, and 4 outputs (C) labeled Q1 to Q4. An auxiliary controller (D) is attached to the right of the main controller and acts as an expansion for inputs/outputs. The auxiliary controller has 8 inputs (E) labeled I1 to I8, and 8 outputs (F) labeled Q1 to Q8.

When the controller is first powered, the POW/RUN light (G) will flash green. When the controller is ready, the POW/RUN light will glow a constant green and the display screen (H) header will read SCOTCHMAN HFA. See FIGURE 18 below.




FIGURE 18

The information displayed on the main controller screen and the associated inputs and outputs of each controller are explained in the following pages.

The screen on the controller displays the total lifetime cuts of the machine, active inputs/outputs, and timeout errors. This information can be seen at any time during operation to aid in troubleshooting. A description of each message and function is described below.

TOTAL CUTS:

The total lifetime AUTO cuts of the machine are displayed on the second line of the display. This value is non-volatile and will continue to count for the lifetime of the PLC. The maximum value this can reach is 65,534. After reaching this value, the count will reset to zero on the next cut.

```
SCOTCHMAN HFA
TOTAL CUTS: 65534
.....
INPUTS
OUTPUTS
.....
```

INPUTS:

The inputs of the PLC are displayed on the third line of the display. Inactive inputs are displayed as a dot (.), whereas active inputs are displayed as a number or letter. Inputs on the main controller are displayed as numbers (1, 2, 3...). Inputs on the auxiliary controller are displayed as letters (A, B, C...). These values correspond with the inputs I1-I8 on each controller. Input I8 on the auxiliary controller is not used.

```
SCOTCHMAN HFA
TOTAL CUTS: *****
12345678 ABCDEFG
INPUTS
OUTPUTS
.....
```

OUTPUTS:

The outputs of the PLC are displayed on the sixth line of the display. Inactive outputs are displayed as a dot (.), whereas active outputs are displayed as a number or letter. Outputs on the main controller are displayed as numbers (1, 2, 3, 4). Outputs on the auxiliary controller are displayed as letters (A, B, C). These values correspond with Q1-Q4 on the main controller and Q1-Q3 on the auxiliary controller. Outputs Q4-Q8 on the auxiliary controller are not used.

```
SCOTCHMAN HFA
TOTAL CUTS: *****
.....
INPUTS
OUTPUTS
1234 ABC
```

TIMEOUT:

The machine has two timeout error messages that will display on the screen for a when an error occurs. The two error messages are:

TIMEOUT SAW: The saw head took too long to reach the head down sensor. If the PLC does not see the head down input within *5 min* of starting a cut, this message will appear and the cut cycle will stop. Press the E-Stop, Head Down, or Cycle button to clear message.

TIMEOUT SHUTTLE: The shuttle vise took too long to reach the shuttle in sensor. If the PLC does not see the shuttle in input within *30 seconds* of starting a shuttle in command, this message will appear. Press the E-Stop to clear message.

```
SCOTCHMAN HFA
TOTAL CUTS: *****
.....
INPUTS      TIMEOUT
OUTPUTS     SAW
.....      SHUTTLE
```

After a timeout error occurs the machine shuts off in the state that it is in. Correct the source of the error and restart the machine as necessary.

The inputs and outputs of the PLC are 24VDC signals. A list of each input/output and their function is listed below. The value displayed on the screen when active is shown in parenthesis (). The wiring schematic (SEE SECTION 14.0) representation is shown in brackets [].

Inputs, Main Controller:

- I1 (1) [1CR] : E-STOP - Activated anytime the saw has been powered up by the START button.
I2 (2) [1LS] : SHUTTLE OUT - Activated when the shuttle vise is in the OUT position. This sensor is located in the base of the shuttle vise where the cylinder attaches.
I3 (3) [2LS] : SHUTTLE IN - Activated when the shuttle vise is in the IN position. This sensor is located on the bottom of the shuttle cylinder, near the rod end.
I4 (4) [3LS] : HEAD UP indicator - Activated when the head is in the UP position.
I5 (5) [4LS] : MATERIAL OUT - Activated when there is no material in the shuttle vise or the cylinder has stroked too far. This sensor is located in the shuttle vise cylinder.
I6 (6) [5LS] : HEAD DOWN indicator - Activated when the head is in the DOWN position.
I7 (7) [3PB] : CYCLE - Activated when the cycle button is depressed.
I8 (8) [4PB] : HEAD DOWN - Activated when the head down button is depressed.

Inputs, Auxiliary Controller:


- I1 (A) [5PB] : HEAD UP - Activated when the head up button is depressed.
I2 (B) [6PB] : TRIM/TEST - Activated when the trim/test button is depressed.
I3 (C) [N] : PARTS COUNT - Activated when the machine reaches its preset count on the parts counter. Inputs preset count met condition to the PLC. The machine will operate indefinitely in the AUTO mode if the counter value is 0.
I4 (D) [2SS] : AUTO/MANUAL - Activated when the AUTO/START/MANUAL switch is in the AUTO position.
I5 (E) [3SS] : INDEX 1 - Activated when the index switch is set to 1 indexes.
I6 (F) [3SS] : INDEX 2 - Activated when the index switch is set to 2 indexes.
I7 (G) [3SS] : INDEX 3 - Activated when the index switch is set to 3 indexes.

Outputs, Main Controller:

- Q1 (1) [1SOL] : SHUTTLE - Activates the shuttle solenoid valve. Shuttle cylinder retracts (out) when output is ON, extends (in) when OFF.
Q2 (2) [2SOL] : SHUTTLE VISE - Activates the shuttle vise solenoid valve. Shuttle vise cylinder extends (closes) when output is ON, retracts (opens) when OFF.
Q3 (3) [3SOL] : HEAD - Activates the head down solenoid valve. Head power down is activated when output is ON, head retracts to UP position when OFF.
Q4 (4) [4SOL] : MATERIAL VISE - Activates the material vise solenoid valve. Material vise cylinder retracts (opens) when ON, extends (closes) when OFF.
SEE SECTION 10.6 for more details.

Outputs, Auxiliary Controller:

- Q1 (A) [2CR] : INCREASE - Activates the relay connected to the increment terminal of the parts counter. This signals the parts counter to increase the part count after a cut has been made in AUTO mode.
Q2 (B) [3CR] : RESET - Activates the relay connected to the reset terminal of the parts counter. This signal resets the active count on the parts counter to 0 after the preset value has been reached.
Q3 (C) [4CR] : MOTOR - Activates the saw motor relay. If the SAW MOTOR ON/OFF switch is in the ON position, the this signal will start the saw motor at the beginning of a cycle.



CPO 315 HFA - HITCH FEED

AUTOMATIC SAW

Ideal for high volume and short length applications that require very accurate and clean cuts; this Hitch Feed Automatic (HFA) cold saw is fully automatic and provides uninterrupted cutting on tubing or solids.

OPTIONAL EQUIPMENT

- **Flood coolant**
- **Form jaws for multiple tubes**
- **Digital read-out for quick easy length setting**
- **Ten-foot or twenty-foot material supply track**

M A D E I N U S A

10.6 PNEUMATIC SYSTEM

REFER TO FIGURE 19 BELOW.

- 1A - 5/16" BLACK TO SAW VISE BACK**
- 1B - 5/16" BLACK TO SAW VISE FRONT**
- 2A - 1/4" RED TO TOP OF POWER DOWN HYD. TANK**
- 2B - 1/4" GREEN TO BOTTOM OF POWER DOWN CYLINDER**
- 3A - 1/4" BLUE TO RIGHT END OF SHUTTLE CYLINDER**
- 3B - 5/16" BLACK TO TOP OF SHUTTLE HYD. TANK**
- 4A - 1/4" BLACK TO BACK OF SHUTTLE VISE**
- 4B - YELLOW TO FRONT OF SHUTTLE VISE**




FIGURE 19

THE MOST COMMON PNEUMATIC/HYDRAULIC PROBLEMS ARE:

- A. Low levels of fluid in the reservoirs. The fluid level in the power down feed reservoir should be approximately 1-1/2 inches below the top of the reservoir with the head in the down position and 2-1/2 inches below the top of the reservoir when the head is in the up position. The fluid level in the shuttle cylinder reservoir should be 1-1/2 inches below the top of the reservoir when the cylinder is completely extended (all the way to the left against the material vise).**

- ☒ CAUTION: THE AIR SUPPLY TO THE MACHINE MUST BE DISCONNECTED BEFORE YOU REMOVE THE FILLER PLUG FROM THE RESERVOIRS. FAILURE TO DISCONNECT THE AIR WILL CAUSE THE FLUID TO BE PURGED OUT THROUGH THE OPENING UNDER PRESSURE!**

- B. Worn seals in the vise or shuttle cylinders. For seal kit installation instructions, REFER TO SECTIONS 8.6 & 8.7.**

- C. Loose connections in the air lines. All of the air lines on this machine are the snap in connector type. To remove the hose, push in on the slide connector while pulling out on the hose. To reconnect the hose, simply push the hose into the connector as far as it will go. If there are any questions about where the hoses connect, REFER TO FIGURE 19 ON THE PRECEDING PAGE.**

11.0 PARTS LISTS

**THE FOLLOWING SECTIONS CONTAIN THE SAW AND OPTIONAL EQUIPMENT PARTS LISTS
AND DRAWINGS FOR YOUR CONVENIENCE, ALWAYS GIVE YOUR COMPLETE SERIAL
NUMBER WHEN ORDERING PARTS!**

11.1 SAW HEAD

ITEM	PART #	DESCRIPTION
A	077150	Needle Bearing
B	077322	Worm Shaft
C	077323	Pivot Bearing
D	077324	Spacer Ring
E	077325	Bearing
F	077330	Hub
G	077326	Spacer Ring
H	077321	Lock Nut
I	077328	Gear Wheel
J	060250	M-10 SHCS
K	075080	Key 8 x 7 x 32
L	077630	Vent
O	077152	Sight Gauge
P	077153	Drain Plug
Q	045380	Head Casting
R	045328	Spacer
S	045324	Chip Shield Assembly
T	073326	M-8 SHCS
U	077333	Worm Wheel
V	077334	Bushing
W	075076	Bearing
X	075075	Seal
Y	077628	Bearing Housing
Z	077624	Saw Spindle
AA	077626	Saw Flange (Includes DD)
BB	221212	M-10 x 30 SHCS
DD	073920	Dowel Pins
EE	073641	M-10 SHCS
FF	077335	Snap Ring
GG	077337	O-Ring
HH	077340	Key 10 x 8 x 32

II	075081
JJ	045327
KK	201120
LL	201135
MM	154004
NN	077630
	045382

O-Ring
 Straps
 M-6 x 20 HHCS
 M-6 x 35 HHCS
 Rivet
 Vent
 Complete Head Assembly





FIGURE 20

11.2 MAIN VISE ASSEMBLY

ITEM	PART #	DESCRIPTION
A	221245	10 x 160mm SHCS
B	221240	10 x 140mm SHCS
C	221235	10 x 100mm SHCS
D	045311	Clevis Guide
E	045312	Clevis
F	045317	Clevis Pin
G	046655	Snap Ring
H	045630	Cylinder
I	045631	Cylinder Seal Kit
J	045313	Cylinder Mount
K	045301	Vise Body
L	045302	Push Block
M	045306	Hold Down Plate
N	221210	M-10 x 25 SHCS
O	045304	Vise Side Plate
P	221412	M-16 x 35 SHCS
Q	045307	Upper Wear Plate
R	230005	M-6 x 12 FSHCS
S	077100	M-10 Dowel Pin
T	045303	End Plate
U	201620	M-16 x 55 HHCS
V	045308	Lower Wear Plate
W	073458	M-6 x 10 SHCS
X	045325	Lead Screw Cover
Y	045602	Spring
Z	201160	M-8 x 60 HHCS
AA	045314	Detent Block
BB	045309	Lead Screw
CC	045198	Drive Forks
DD	045310	Boss
EE	077121	M-20 Jam Nut
FF	045030	1169 x 5 x 65 90 Degree Elbow
GG	045305	Guide Plate
HH	046652	Detent Ball
II	221210	M-10 x 25 SHCS

JJ	219047	M-10 x 12 Set Screw
KK	077798	Vise Jaws
LL	203212	M-10 x 30 HHCS
MM	045224	Clevis Wear Plate
NN	060270	1-3/4" Hole Plug
OO	045329	Angle Shelf
PP	073626	M-10 x 20 SHCS
QQ	114020	Washer
RR	060270	End Cap
SS	210012	M-10 Jam Nut
	045300	Complete Vise Assembly

FIGURE 21

11.3 SHUTTLE VISE ASSEMBLY

ITEM	PART #	DESCRIPTION
A	111015	5/8 x 11 Jam Nut
B	045219	Boss
C	045652	Cylinder Body
CA	045662	Cylinder Rebuild Kit - Shuttle Vise
D	045220	Cylinder Mounting Plate
E	077743	Fitting
F	045221	Detent Block
G	046652	Detent Ball
H	218048	M-10 Set Screw
I	220027	M-8 x 35 RHMS
J	201160	M-8 x 60 HHCS
K	045212	Lead Screw
L	045210	Push Block
M	045211	Keeper Plates
N	077864	M-5 x 12 SHCS
O	045215	Vise Body
P	045208	Teflon Bushing
Q	045217	Alignment Probe
R	077795	Proximity Switch
S	045216	Alignment Cap
T	073458	M-6 x 10 SHCS
U	045213	End Block
V	221417	M-16 x 45 SHCS
W	230005	M-6 x 12 FSHCS
X	073925	1/4 x 1/2 Dowel Pin
Y	045214	Slide Plate
Z	220027	M-8 x 35 BHCS
AA	045222	End Plate
BB	045654	Seal Kit
CC	045199	Piston
DD	077798	Shuttle Jaws
EE	203212	M-10 x 30 SHCS
FF	045602	Spring
GG	210012	M-10 Jam Nut
HH	046667	O-Ring

II	045661	Reed Switch P8S-GRFAX Serial# of Saw Required!!
JJ	073626	M-10 x 20 SHCS
KK	046669	Large Wire Clip
LL	073458	M-6 x 10 SHCS
MM	046668	Small Wire Clip
NN	010070	Wiper Seal
OO	218007	M-4 x 4 Set Screw
PP	220027	M-8 x 35 BHCS
QQ	045209	Complete Vise Assembly
RR	060270	End Cap
SS	045660	Magnet
TT	220010	M-4 x 12 BHCS
UU	114020	Washer
VV	045621	Cable Track Bracket
WW	045376	Angle Mount
XX	221010	M-6 x 16 SHCS
YY	045620	Cable Track (not shown)




FIGURE 22

11.4 SHUTTLE ASSEMBLY

ITEM	PART #	DESCRIPTION
A	077742	1/4 Inch NPT x 169 Plastic
B	077701	Filter
C	077777	3/8 NPT Filler Plug
D	077774	3/8 Inch NPT Nipple
E	077712	Flow Control Valve
F	045042	1168 x 1/2 Male Connector
G	045048	Line (Cylinder 1/2)
H	060501	Line (Valve 5/16)
I	077738	1/4 Inch NPT x 169 Plastic
J	204225	M-10 x 60 HHCS
K	045661	Reed Switch P8S-GRFAX
L	045054	11699 x 3/8 Ninety Degree Elbow
M	221120	M-8 x 25 SHCS
N	045640	Shuttle Cylinder
N1	045643-045661	Shuttle Cylinder (Ser. #'s 1320HFA & Prior)
N2	045643	Shuttle Cylinder (Ser. #'s B1328HFA & Up)
N3	045641	Rod Seal Kit
N4	045642	Piston Seal Kit
O	219040	M-10 x 10 Set Screw
P	045265	Mounting Bracket (Cylinder End)
	045195	Set
Q	230005	M-6 x 12 FSHCS
R	045423	Shroud
S	045225	Scale
T	201220	M-10 x 50 SHCS
U	114020	M-10 Hardened Washer
V	045370	Pointer
W	220010	M-4 x 12 BHCS
X	201232	M-10 x 80 HHCS
Y	045266	Front Guide
Z	045204	Sliding Stop
AA	045202	Mounting Bracket (Vise End)
	045195	Set of Guide Blocks
BB	045207	Linear Shafts
CC	045209	Shuttle Vise Assembly

DD	045201
EE	045284
FF	045197
GG	230207
HH	218000
II	045254
JJ	221212
KK	045259
LL	221210

Rear Plate
Reservoir
Adjustable Wear Plate
M-10 x 20 FSHCS
M-8 x 8 Set Screw
Roller
M-10 x 30 SHCS
Roller Block
M-10 x 25SHCS




FIGURE 23

11.5 FINE ADJUSTMENT STOP ASSEMBLY

ITEM	PART #	DESCRIPTION
A	045205	Fine Adjustment
B	045206	Adjustment Collar
C	016063	1-1/2 Snap Ring
D	046652	Detent Ball
E	045602	Detent Spring
F	045204	Sliding Stop
G	204225	M-10 x 60 HHCS
H	221212	M-10 x 30 SHCS
I	045259	Roller Block
J	045254	Roller
K	114020	Hardened Washer
L	045233	Roller Bearing (Not Pictured)
M	047255	Roller Set (Includes J & L)
N	045256	Dowel Pin




FIGURE 24

11.6 POWER DOWN FEED ASSEMBLY

ITEM	QTY	PART #	DESCRIPTION
1	1	045230	Power Down Bracket (Upper)
2	1	045425	Power Down Reservoir
*3	1	045692	CPO315 PD Cylinder Assembly (Includes Items 3-14)
4	1	045031	3/8" NPT X 1/4" 90° Swivel
5	1	045054	3/8" NPT X 1/2" 90° Swivel
6	1	045593	Pivot Pin (Includes Items 6-7)
7	2	016402	Snap Ring
8	1	045594	PD Clevis Drill
9	1	045693	Bellow Clamp For 045697
10	1	045696	Bellow Retainer
11	1	045697	Bellow For *045699
12	1	077715	Cylinder Pivot Bolt (2)
13	2	218022	M6 X 6MM DIN916 Set Screw
14	2	220014	M6 X 10MM DIN BN19 BHCS
15	1	045698	Cylinder Seal Kit For *045699
16	2	077211	Return Spring
17	8	221210	M10 X 25MM DIN912 SHCS

***P/N 045699 Cylinder - Only available as 045692 Assembly**




FIGURE 25

11.6A POWER DOWN FEED VALVES

ITEM	PART #	DESCRIPTION
A	077746	1/4" NPT x 169 PL
B	077701	Baffle
C	077777	3/8" NPT Plug
D	045054	Ninety Degree Swivel
E	077536	Check Valve
F	045042	Return Line Fitting
G-H-I		MVK6 Mounting Kit
J	047535	Flow Control Valve
K	045054	1/4 NPT x 1/2 PL Ninety Degree Swivel
L	045041	Brass 3-Way
M	077779	1/4 NPT Nipple
N	077771	Reducer
O	078455	Sight Glass




FIGURE 26

11.6B AIR CONTROLS

ITEM	PART #	DESCRIPTION
A	N/A	Provided by Customer
B	077719	Shuttle Valve
C	077737	1/4 NPT Brass Street Elbow
D	077780	Brass NPT Coupler
E	077779	1/4" NPT Nipple
F	045604	Complete Filter/Regulator/Lubricator
G	045605	Mounting Brackets
H	077738	90 Degree Fitting
I	045609	Replacement Bowls
J	045610	Filter Seal Kit
K	045612	Regulator Seal Kit
L	045613	Lubricator Seal Kit
M	045176	Valve Mount
N	045606	Gauge




FIGURE 27

11.7 AIR VALVE ASSEMBLY

ITEM	PART #	DESCRIPTION
A	046047	DIN Connector for 060040
B	077744	Fitting (5/16 PL to 1/4 NPT)
C	077777	Plug (3/8 NPT)
D	045045	ASP-3BV Breather)
E	077740	3/8" 90 DEG Male Swivel
F	045650	Solenoid 24VDC
G	045655	Valve (Includes F)
H	677728	Fitting (1/4 NPT to 1/4 Hose)
I	077779	1/4" X Close Brass Nipple
J	077741	1/8" Male SW x 169 PL
K	077750	1/8" NPT X 2-1/2" Nipple
L	077721	1/8" X 1/4" Brass Bushing
M	677745	1/4" Brass Tee
N	045653	4 Station Valve Assembly All Except: H, I, J, K, L, M, & O
O	077930	Mister Regulator





FIGURE 28

11.8 BLADE GUARD ASSEMBLY

ITEM	PART #	DESCRIPTION
A	045267	Guard Shell
B	073641	M-10 SHCS
C	040087	M-10 Brass HHCS
D	208012	M-10 Jam Nut
E	026621	M-10 Tee Nut
F	073766	Coolant Line
G	046269	Hose Barb
H	073450	M-4 x 16 SHCS
*I	076839	Mister Unit (Standard)
J	676842	Hose Barb
K	077926	Coolant Line
L	060501	5/16 Air Line
M	676844	Fitting
N	073095	M-4 Washer
O	073415	M-4 SHCS
P	046267	Elbows
Q	073766	Coolant Line
R	046268	T Mount
S	026619	M-10 Tee Nut

*** Mister is standard equipment - Flood Coolant is optional**




FIGURE 29

11.9 MOTOR ASSEMBLY

ITEM	PART #	DESCRIPTION
A	046358	Angled Fan Cover
B	073407	M-5 x 8 SHCS
C	N/A	Fan
D	N/A	End Casting
E	077325	Motor Bearing
F	N/A	Snap Ring
G	076369	Key
H	203210	M-10 SHCS
I	077370	Key 6 x 4 x 32mm
J	N/A	Seal
K	N/A	Spacer Washer
L	N/A	Snap Ring (30mm Only)
M	N/A	End Casting (Front)
N	077375	Pinion Gear
O	077189	Lock Nut
P	077860	350 Head Gasket
Q	077855	Switch Box Gasket (Not Shown)

COMPLETE MOTORS

A	076993	11-177 RPM/230/460 Volt
----------	---------------	--------------------------------





FIGURE 30

11.10 ELECTRICAL UNIT - LINE CIRCUIT

ITEM	PART #	DESCRIPTION			
A	011854	Disconnect Switch	G	048039	Motor Protect Switch (0.4 Amp) (Optional Flood Coolant Pump)
B	011933	Fuse 1-1/2 AMP Primary	H	078285 078286	5HP 230V VFD-Programmed 5HP 460V VFD-Programmed
C*	011930*	Transformer 150VA - Replacement	I	045636	EASY-E4-UC PLC (not shown)
D	011835	Secondary Fuse 2 AMP	J	045637	EASY-E4-UC Expansion Module (not shown)
E	045714	Power Supply HFA 01-14	K	045681	Pump Contactor
F	000943	460V Motor Protect Switch (10-16 Amp)	L	045683	Control Relay (1CR, 2CR, 3CR, & 4CR) (not shown)
F1	000942	230V Motor Protect Switch (16-20 Amp)	M	028483	Control Relay (5CR) (not shown)

C* - REPLACEMENT PART - Not exactly the same - but will fit.

FERROUS HFA




F	UPDATED BRANCH CIRCUIT PROTECTION INFO; ADDED 460V VOLTAGE; UPDATED 1MCP CIRCUIT PROTECTOOR	7/22/22	GRQ	CAH
E	UPDATED EATON EASY RELAY	04/27/22	GRQ	ABS
D	ADDED 5CR RELAY	01/18/21	GRQ	DMC
C	CHANGED FUSE *2FU TO *10FU	08/24/17	GRQ	DMC
REV	DESCRIPTION	DATE	BY	APPR.

Model:	45355	Drawn By:	GRQ	Date:	05-19-2016	Rev:	F
SCOTCHMAN INDUSTRIES		Description:					
180 E US-14		HITCH FEED CONTROL PANEL					
Philip, SD 57567		Drawing Number:			Sheet		
		045355-E1			1		
					Of		
					2		

S/N B1491 HFA 0622 & UP

FIGURE 31



Model:	45355	Drawn By:	GRQ	Date:	05-19-2016	Rev:	F
SCOTCHMAN INDUSTRIES		Description					
180 E US-14		HITCH FEED CONTROL PANEL					
Philip, SD 57567		Drawing Number:			Sheet		
		045355-E2			2		Of 2

FERROUS HFA


S/N B1491 HFA 0622 & UP

FIGURE 31A

Page 75A

Scotchman

Metal Fabricating Solutions



MADE IN USA

11.11 ELECTRICAL UNIT - SECONDARY CIRCUIT

ITEM	PART #	DESCRIPTION
A	011879	Start Button
A1	048047	24 Volt Lamp
A2	048050	KM/AFR Red "Power On"
B	011879	Start Button
C	011837	Emergency Stop Switch
D	011872-011867-048108 & (2) 011874	Hitch Selector Switch
E	011879	Start Button
F	011879	Start Button
G	011877	Selector Switch
H	011879	Start Button
I	011877	Selector Switch
J	045557	Potentiometer
J1	044125	VFD Legend
K	045543	Counter (For HFA)
L	011877	Selector Switch




FIGURE 31B

11.12 BASE ASSEMBLY

ITEM	PART #	DESCRIPTION
A	045171	Base Cabinet
B	045413	Base Casting
C	045735	Lower Enclosure
D	046642	Door Assembly
E	045257	Reservoir Screen
F	060150	230 Volt Coolant Pump
F1	060158	460 Volt Coolant Pump
F2	060160	575 Volt Coolant Pump
G	049217	Leveling Pads
G1	208024	M-24 Hex Nut
H	073350	M-10 x 100 HHCS
I	221010	M-6 x 16 SHCS
J	203235	M-10 x 90 HHCS
K	114020	Washer
L	045475	Chip and Parts Chute
M	221120	M-8 x 25 SHCS
N	045052	Chip Bucket
O	060149	Pump Screen
P	046018	Handle
Q	049330	Brackets
R	216015	M-10 Flange Nut
S	073617	M-6 x 12 BHCS
T	046642	Access Cover
U	220010	M-4 x 12 BHCS




FIGURE 32

11.13 COOLANT PUMP

(OPTIONAL FLOOD COOLANT)

ITEM	PART #	DESCRIPTION
A	060150	230 Volt Coolant Pump
A1	060158	460 Volt Coolant Pump
A2	060160	575 Volt Coolant Pump
B	060152	Impeller (obsolete)
C		N/A
D	060151	Pump Oil Seal
E	N/A	Bolt
F	N/A	Bolt
G	060080	90 Degree Elbow (Not Shown)
H	060140	Coolant Line
I	060095	Pump Cable
J	221005	M-6 x 12 SHCS
K1	072354	3/8 NPT Hose Barb
K2	072322	3/8" Ball Valve
K3	077774	3/8 NPT Close Nipple
K4	046271	Elbow
L	046300	Hose Clamp (Not Shown)
M	060149	Pump Screen




FIGURE 33

11.14 STROKE CONTROL ASSEMBLY

ITEM	PART #	DESCRIPTION
A	045253	Stroke Adjustment Plate
B	045249	Stroke Control Stand
C	045299	Stop Block
D	045320	Stroke Sensor Mount
E	045330	Stop Guide
F	220010	M4 X 10MM BHCS
G	203212	M-10 x 30 HHCS
H	114020	3/8" Hard Washer
I 1	077796	Proximity Sensor (OLD M18 - One Used)
I 2	077795	Inductive Prox. Sensor (NEW M12 - Two Used)
		<u>NOTE: Verify Size Before Ordering!!</u>
J	221212	M-10 x 30 SHCS
K	221210	M-10 x 25 SHCS
L	221120	M-8 x 25 SHCS
M	158202	Bumper
N	073095	M-4 Washer




FIGURE 34

11.15 HOOD ASSEMBLY

ITEM	PART #	DESCRIPTION
A	203217	M-10 x 45 HHCS
B	045196	Pedestal
C	045285	Pivot Pin
D	046018	Hood Handle
E	045464	Extension
F	045322	Sight Glass
G	046645	Sight Glass Seal
H	201120	M-6 x 20 HHCS
I	077157	M-6 Nylon Loc Nut
J	229415	M-10 x 12 x 16 Shoulder Bolt
K	045255	Hood
L	077142	Grease Nipple
M	077100	M-10 Dowel Pin
N	073617	M-6 x 12 BHCS
O	040012	Bumpers
P	047110	Interlock Switch
P1	047115	Switch Mount
P2	220010	M-4 x 12 BHCS
P3	21500	M-4 Nylon Loc Nut
Q	047160	Hood Assembly (Includes D, E, F, G, H, I, K, N, O, P, R)
R	215013	M-8 Nylon Loc Nut
S	077907	Shroud Edge




FIGURE 35

12.0 OPTIONAL EQUIPMENT PARTS LISTS

12.1 TEN FOOT SUPPLY TRACK

ITEM	QTY	PART #	DESCRIPTION
1	1	029242	10' Roller Conveyor W/Legs (Complete Assy.)
2	2	029243.1	10' Roller Conveyor Side
3	2	029244	Leg Roller Conveyor
4	10	029245	Replacement Rollers For #29243
5	1	029300	Conveyor Brace
6	3	029621	Conveyor Support Bracket
7	12	201205	M10 X 16MM DIN933 HHCS
8	12	208012	M10 DIN 934 Hex Nut
9	2	216015	M10 BN190 Flange Nut
10	2	224205	M10 X 16MM DIN-BN73 WLCS

***076938 - 13" GUIDE ASSEMBLY (Optional)**

ITEM	QTY	PART #	DESCRIPTION
1	2	026619	SMALL TEE NUT (M10)
2	2	043003	NYLON ROLLER 3.25
3	2	076941	BASE CLIP
4	1	076943	BASE MATERIAL GUIDE 13" PAINT
5	2	214012	M10 DIN125 REGULAR WASHER
6	2	221120	M8 X 25 DIN9121580 12.9 SHCS
7	2	229225	M10 X 12 X 70 SB912

* 076935 - Optional Guide Assembly for older conveyors




FIGURE 36

12.2 CUTTING COOLANTS AND LUBRICANTS

PART #	DESCRIPTION
075751	1 GA. SAW COOLANT
075752	5 GA. SAW COOLANT
075754	55 GAL. SAWING COOLANT
075756	1 GAL. STAINLESS COOLANT
075757	5 GAL. STAINLESS COOLANT
075753	1 QT AIRLINE LUBE ORM-D
075759	1 GAL AIRLINE ORM-D
075758	GEAR OIL - HEAD

12.3 MAIN VISE REGULATOR

ITEM	PART #	DESCRIPTION
A	078190	REGULATOR W/GAUGE
B	677934	NF-FRL WALL MOUNT BRACKET
C	077864	M5 X 12 DIN912 SHCS
D	077742	1/4" MALE SW X169PL
E	077744	1/4-5/16 NPT STR FITTING
F	060501	5/16" BLACK AIR TUBE
	047250	AIR REG RFA VISE (MAN PK)




FIGURE 37

12.4 SHUTTLE VISE REGULATOR

ITEM	PART #	DESCRIPTION
A	078190	Regulator
B	677934	Regulator Mount
C	077864	M-5 x 12 SHCS
D	077746	1/4" x 90 Degree Swivel Fitting
E	077721	Bushing
F	077750	Nipple






FIGURE 38

13.0 SAFETY VALVE / SOLENOID








SAFETY VALVE / SOLENOID DETAIL




PARTS LIST			
ITEM	QTY	PART #	DESCRIPTION
1	2	201135	M6 X 35MM HHCS
2	2	073206	M6 HEX NUT
3	1	077740	3/8" 90° MALE SWIVEL
4	1	045030	1169X5X6SZ ELBOW 90° MALE
5	1	044110	24V AIR VALVE


14.0 WIRING DIAGRAMS



S/N B1491 HFA 0622 & UP



S/N B1491 HFA 0622 & UP



CONT.
NEXT
PAGE

CONT.
NEXT
PAGE







CONT.
NEXT
PAGE

S/N B1491 HFA 0622 & UP

15.0 STOCK BLADES

315 MM (12-1/2 Inch) x 40 Bore (Pin Spacing 2/8/55 & 4/12/64)

ITEM	PART #	DESCRIPTION
A	074355	90 Tooth 12-1/2" (315mm) Dia.
B	074356	100 Tooth 12-1/2" (315mm) Dia.
C	074357	110 Tooth 12-1/2" (315mm) Dia
C	074345	120 Tooth 12-1/2" (315mm) Dia.
D	074348	150 Tooth 12-1/2" (315mm) Dia.
E	074350	180 Tooth 12-1/2" (315mm) Dia.
F	074352	220 Tooth 12-1/2" (315mm)Dia.
H	074354	280 Tooth 12-1/2" (315mm)Dia.



STYLE 2

STYLE 2A

STYLE 3

NOTCH GRIND

Standard on
POWER 2000
and
PERFORMANCE
3000
BLADES

275 MM (10-3/4 Inch) x 40 Bore (Pin Spacing 2/8/55 & 4/12/64)

ITEM	PART #	DESCRIPTION
A	074360	90 Tooth 10-3/4" (275mm) Dia.
B	074361	100 Tooth 10-3/4" (275mm) Dia.
C	074362	120 Tooth 10-3/4" (275mm) Dia.
D	074363	150 Tooth 10-3/4" (275mm) Dia.
E	074365	180 Tooth 10-3/4" (275mm) Dia.
F	074366	220 Tooth 10-3/4" (275mm) Dia.
G	074367	260 Tooth 10-3/4" (275mm) Dia.

THERE ARE FOUR STYLES OF BLADES AVAILABLE:

STYLE 2 has a round back tooth with a square face and top. This style is designed for thin wall non-ferrous tubes, plastics and synthetics.

STYLE 2A is an alternate top bevel grind. This grind is generally used on blades that have 220 teeth or more.

STYLE 3 is a triple chip grind with a high/low tooth form. This grind is generally used on blades that have 220 teeth or less.

NOTCH GRIND has notches on top of every tooth to break up the chip during the cut. This is the standard grind on our TiN coated POWER 2000 blades and PERFORMANCE 3000 blades. This grind is generally used on blades that have 220 teeth or more cutting thin-walled tube. This grind can also be used on our standard blades as well.